

How to set your **HUNTER CLOCK**

General Clock Features

Remember to Water Smart.

Most clocks will have a main dial that prominently displays each of the five essential settings you'll need to water wisely.

1. From each position on the dial, you may use the plus or minus key to adjust those settings upward or downward, or even to add or take away watering days.



2. You will also see a forward arrow or a button that says "Next". This will allow you to toggle to the next feature you want to set.



How to set your **HUNTER CLOCK**

Set Date and Time

Remember to Water Smart.

The first settings you'll adjust on your irrigation clock are the date and time.

To set your clock's date and time:

1. Turn dial to the "Current Date/Time" position.
The current year will be flashing.
2. Use plus or minus key to change year.
3. Push the forward arrow to set the month.
4. Follow the same steps to set "Day/Time".
5. When you're finished, set the dial to the "Run" position.



How to set your **HUNTER CLOCK**

Set Program A and B

Remember to Water Smart.

The “Program” option is important if your landscape contains both lawn watered by sprinklers and plants watered by drip irrigation.

To set your clock’s A and B programs:

- 1.** Set your sprinkler watering to run from “Program A”, and drip watering to run from “Program B”.
If your landscape is watered by drip irrigation only, then your drip can be set on your “Program A” as your only program.
- 2.** Proceed to set watering days, watering start times and watering run times for “Program A” and/or “Program B”.



How to set your **HUNTER CLOCK**

Set Days to Water

Remember to Water Smart.

The next essential clock setting is the “Days of the Week” function, which tells your clock which days to water. Your clock may display this as “Set Days to Water”.

To set your clock’s Watering Days:

- 1.** Turn the dial to “Set Days to Water”.
- 2.** Press the plus button to activate a particular day of the week to water.
- 3.** The minus button cancels watering. Keep going through each day until you have all your watering days either turned off or on.
- 4.** After programming, set the dial to “Run” or “Auto”.




How to set your **HUNTER CLOCK** Set Watering Start Times

Remember to Water Smart.

The irrigation clock "start times" allows you to tell the clock when, or what time(s) of the day, you want to water. The wording on your clock may vary.

To set your clock's Watering Start Time:

1. Look for the phrase "Set Watering Start Time".
With the dial here, press the plus and minus buttons to change the start time.
2. Press the forward buttons to add additional start times if you want to water more than once a day.
3. To eliminate a start time, press the plus or minus buttons until your display says "off".
4. Keep going through each day until you have all your watering days either turned off or on.
5. After programming, set the dial to "Run" or "Auto".



How to set your **HUNTER CLOCK**

Set Watering Run Times

Remember to Water Smart.

When you set the run time, you are telling the clock how many minutes to water each time it's set to turn on.

To set your clock's Watering Run Times:

1. Move clock dial to select "Station Run Times".
2. Adjust the minutes to set how long you want each station to run by using the plus/minus keys.
3. The forward arrow will advance to each station.
4. After programming, set the dial to "Run" or "Auto".



How to set your **HUNTER CLOCK** Setting Manual Operations

Remember to Water Smart.

If you need to run your irrigation system manually, follow the steps below.

To set your clock's Manual Operations:

1. Turn the dial to the "Manual Single Station" position.
The station run time will flash in the display.



2. Use the arrow to move to the desired station.



3. Use the plus button to set how long you want the system to run, usually no more than two minutes.



4. When you're finished operating your irrigation system manually, turn the dial back to the "Run" position.

