


# How to set your **ORBIT CLOCK** General Clock Features

Remember to Water Smart.

Most clocks will have a main dial that prominently displays each of the five essential settings you'll need to water wisely.

1. From each position on the dial, you may use the plus or minus key to adjust those settings upward or downward, or even to add or take away watering days.



2. You will also see a forward arrow or a button that says "Next". This will allow you to toggle to the next feature you want to set.



# How to set your **ORBIT CLOCK**

## Set Date and Time

Remember to Water Smart.

The first settings you'll adjust on your irrigation clock are the date and time.

### To set your clock's date and time:

1. Turn dial to the "Time/Date" position. A time will appear with three arrows pointing to the year, month and day.
2. Use the plus or minus keys to set the time, then press "Enter". A blinking cursor will appear below the arrow for the year, month, and day.
3. Use plus or minus key to adjust the year, press "Enter".
4. Repeat steps to set month and date.
5. When you're done, turn the dial back to the "Auto" position.



# How to set your **ORBIT CLOCK**

## Set Program A and B

Remember to Water Smart.

The “Program” option is important if your landscape contains both lawn watered by sprinklers and plants watered by drip irrigation.

### To set your clock’s A and B Program:

1. Set your sprinkler watering to run from “Program A”, and drip watering to run from “Program B”. If your landscape is watered by drip irrigation only, then your drip can be set on your “Program A” as your only program.
2. Proceed to set watering days, watering start times and watering run times for “Program A” and/or “Program B”.



# How to set your **ORBIT CLOCK**

## Set Watering Days

Remember to Water Smart.

The next essential clock setting is the “Days of the Week” function, which tells your clock which days to water. Your clock may display this as “Day of Week”.

### To set your clock’s Watering Days:

1. Turn dial to “Day of Week” in “Program A” or “B”.




2. Press “Enter” to activate watering on Monday. An arrow will appear under the letter “M” and the cursor will advance to Tuesday, or letter “T”.



3. Press “Enter” to activate each day to water.



4. To skip a day, press “Next”.



5. When you’re done, turn the dial back to the “Auto” position.



# How to set your **ORBIT CLOCK** Set Watering Start Times

Remember to Water Smart.

The irrigation clock "start times" allows you to tell the clock when, or what time(s) of the day, you want to water.

## To set your clock's Watering Start Time:

1. Look for "Cycle Start Times" on your clock. With the dial set to "Program A" or "B", press plus or minus button to select the time for "Cycle Start 1".
2. When you press "Enter", the display will advance to Start 2.
3. Repeat steps to add additional start times if you want to water more than once a day.
4. When you're done, turn the dial back to the "Auto" position.




# How to set your **ORBIT CLOCK** Set Watering Run Times

Remember to Water Smart.

When you set the run time, you are telling the clock how many minutes to water each time it's set to turn on.

## To set your clock's Watering Run Times:

1. Move the clock dial to select "Station Duration" in "Program A" or "B".
2. Adjust the minutes to set how long you want each station to run by using the plus and minus keys. Press "Enter".
3. When minutes are set, "A" or "B" will appear over Station 1 and the cursor will advance to Station 2. Repeat step for all stations on the program.
4. To skip a station, press the "Next" key.
5. When you're done, turn the dial back to the "Auto" position.



# How to set your **ORBIT CLOCK** Setting Manual Operations

Remember to Water Smart.

If you need to run your irrigation system manually, follow the steps below.

## To set your clock's Manual Operations:

1. Turn the dial to "Auto".
2. Press the "Manual" key and press "Next" three times. Display will show blinking cursor on Station 1 along with "MINS" for minutes.
3. Use plus button to set how long you want the system to run, usually no more than two minutes.
4. Press "Enter" to begin watering.

