

How to set your **RAIN BIRD CLOCK**

General Clock Features

Remember to Water Smart.

Most clocks will have a main dial that prominently displays each of the five essential settings you'll need to water wisely.

1. From each position on the dial, you may use the plus or minus key to adjust those settings upward or downward, or even to add or take away watering days.



2. You will also see an "Enter" button which will allow you to toggle to the next feature you want to set.



How to set your **RAINBIRD CLOCK**

Set Date and Time

Remember to Water Smart.

The first settings you'll adjust on your irrigation clock are the date and time.

To set your clock's date and time:

1. Turn the programming dial to the "Date/Time" position.



2. Use the plus or minus key to set current year.



3. Press "Enter" to set the month, day and time.



4. Press "Enter" when done.



How to set your **RAINBIRD CLOCK**

Set Program A and B

Remember to Water Smart.

The “Program” option is important if your landscape contains both lawn watered by sprinklers and plants watered by drip irrigation.

To set your clock’s A and B Program:

1. Set your sprinkler watering to run from “Program A”, and drip watering to run from “Program B”.
If your landscape is watered by drip irrigation only, then your drip can be set on your “Program A” as your only program.
2. Turn the dial to “Day Cycle” and press the “Program” button until the screen shows the desired program (A, B, or C).
3. Proceed to set watering days, watering start times and watering run times for “Program A” and/or “Program B”.



How to set your **RAINBIRD CLOCK**

Set Watering Days

Remember to Water Smart.

The next essential clock setting is the “Days of the Week” function, which tells your clock which days to water. Your clock may display this as “Water Day”.

To set your clock’s Watering Days:

1. Turn the dial to “Water Day”. Numbers 1 through 7 will appear for each day of the week.
2. Press plus button to activate day(s) of the week.
3. The minus button cancels watering.
4. Press “Enter” after each day to set watering days.



How to set your **RAINBIRD CLOCK**

Set Watering Start Times

Remember to Water Smart.

The irrigation clock "Start Times" allows you to tell the clock when, or what time(s) of the day, you want to water.

To set your clock's Watering Start Time:

1. Look for the phrase "Start Time".
2. Press the plus or minus button to change the start time.
3. Press the "Forward" arrow to add additional start times for more than once a day.



How to set your **RAINBIRD CLOCK**

Set Watering Run Times

Remember to Water Smart.

When you set the run time, you are telling the clock how many minutes to water each time it's set to turn on.

To set your clock's Watering Run Times:

1. Move clock dial to select "Station Run Time".



2. Use plus or minus key to adjust minutes on each station.



3. Press "Enter" to display and set additional stations.



4. After programming, turn dial to "Auto" position.



How to set your **RAINBIRD CLOCK**

Setting Manual Operations

Remember to Water Smart.

If you need to run your irrigation system manually, follow the steps below.

To set your clock's Manual Operations:

1. Turn the dial to the "Manual Station" position.
It will automatically display station 1, followed by three zeros since the run time has not been selected yet.
2. Use the plus button to set how long you want the system to run, usually no more than two minutes.
3. Press "Enter" to begin watering.
4. After programming, turn dial back to "Auto".

