

How to set your **TORO CLOCK**

General Clock Features

Remember to Water Smart.

Most clocks will have a main dial that prominently displays each of the five essential settings you'll need to water wisely.

1. From each position on the dial, you may use the plus or minus key to adjust those settings upward or downward, or even to add or take away watering days.



2. You will also see a forward arrow or a button that says "Next". This will allow you to toggle to the next feature you want to set.



How to set your **TORO CLOCK**

Set Date and Time

Remember to Water Smart.

The first settings you'll adjust on your irrigation clock are the date and time.

To set your clock's date and time:

1. Turn dial to the "Current Time/Day" position.
2. Time of day will be displayed in hours and minutes.
3. Use "Plus/On" or "Minus/Off" button to adjust the hour.
4. Press "Next" to set date and time.
5. Repeat steps to adjust Minutes /Year/Month/Day.
6. When you're done, turn the dial back to the "Run" position.



How to set your **TORO CLOCK**

Set Program A and B

Remember to Water Smart.

The “Program” option is important if your landscape contains both lawn watered by sprinklers and plants watered by drip irrigation.

To set your clock’s A and B Program:

- 1.** Set your sprinkler watering to run from “Program A”, and drip watering to run from “Program B”.
If your landscape is watered by drip irrigation only, then your drip can be set on your “Program A” as your only program.
- 2.** Proceed to set watering days, watering start times and watering run times for “Program A” and/or “Program B”.



How to set your **TORO CLOCK**

Set Watering Days

Remember to Water Smart.

The next essential clock setting is the "Days of the Week" function, which tells your clock which days to water. Your clock may display this as "Watering Days".

To set your clock's Watering Days:

1. Turn the control dial to the "Watering Days" position and press the "Next" button.
2. "SU" for Sunday will be flashing. Press "Plus/On" button to select or "Minus/Off" button to remove Sunday as a watering day.
3. "MO" for Monday will begin flashing. Continue to select or remove each day of the week until only desired watering days are displayed.
4. After programming, set the dial to "Run".



How to set your **TORO CLOCK**

Set Watering Start Time

Remember to Water Smart.

The irrigation clock “start times” allows you to tell the clock when, or what time(s) of the day, you want to water.

To set your clock’s Watering Start Time:

1. Look for the phrase “Program Start Times”. With the dial here, you’ll see the number 1 flashing.
2. Press “Next” to set the hour, using the “Plus/On” or “Minus/Off” buttons until the desired number is flashing. Press “Next” again to set the minutes.
3. Continue the steps to add additional start times if you want to water more than once a day.
4. Repeat the steps for each day until start times for all days have been programmed.
5. After programming, return the control dial to “Run”.



How to set your **TORO CLOCK** Set Watering Run Times

Remember to Water Smart.

When you set the run time, you are telling the clock how many minutes to water each time it's set to turn on.

To set your clock's Watering Run Times:

1. Move the clock dial to select "Set Station Times". Station number one will be flashing.
2. Press the "Plus/On" or "Minus/Off" button to adjust the number of minutes you want each station to run.
3. Press "Next" to set the next station number. Repeat the steps as needed.
4. When you're done, turn the dial back to the "Run" position.



How to set your **TORO CLOCK** Setting Manual Operations

Remember to Water Smart.

If you need to run your irrigation system manually, follow the steps below.

To set your clock's Manual Operations:

1. Ensure the dial is in the "Run" position.
2. Select the program you wish to start and press the "Manual Start" button two times to begin watering.
3. Station one will be flashing and the controller will automatically run through each station of the program. To manually water one station at a time, press "Next."
4. When you're done, turn the dial back to the "Run" position.

